

AR-15

Disassembly



First you pull back on the charging handle, hold the bolt open and make sure its empty. Next step once you are sure its empty



Let the bolt go forward so you can take the rifle down, push lever in picture and the bolt will close.



Next push in on the rear pin.



Pull pin on the other side as far as it will go.



Now you can open the rifle.



Next step is to remove the bolt, I also take out the charging handle but you don't have to if you don't want to start. Just pull the bolt out.



Now the bolt is out of the rifle.



next we want to take the bolt apart. Take a small punch of the tip of a .223 round and push out the cotter pin in the rear of the bolt.



Ok now you pull it out from the other side.



Tip the bolt on its back and the firing pin should come right out.



Next step you want to take out the pin that runs though the bolt, twist it a bit so it clears the gas tube on the bolt



It should come right out once you rotate it clear.



Now you can take the bolt out of the bolt carrier.



Also if you want you can totally separate the upper from the lower by taking out the other pin in the front. As for cleaning solvents, use break free CLP and some Hoppes #9. It helps to also have some Q-tips to clean where the bolt fits into the upper receiver and pipe cleaners for the gas tube as well.



Clean good in here, and there you have it.. fully disassembled